

Guarded paddle with sides

Article number: SR318

For use with Merrychef eikon® model(s):

□ e2 e2s e3 e4 e4s e5

Key benefits:

- Side wall support to help taking food in and out of the high speed oven
- Hand guard offers protection from heat
- Easy to clean
- Lightweight aluminium paddle



Specifications:

- Dimensions: 298 mm x 300 mm (11.7" x 11.8")

Recommended application:

To be used for taking all food items in and out of the high speed oven

Cleaning:

Wipe clean with a soft cloth or sponge in warm soapy water. To avoid damage always follow the recommended cleaning procedure. Do not use hard abrasives or wire wools on accessories.

Dimensions:

