


Guarded paddle with sides

Article number: SR320

For use with Merrychef eikon® model(s): \square e2 \square e2s \square e3 \square e4 \square e4s \square e5

Key benefits:

- · Side wall support to help taking food in and out of the high speed oven
- Hand guard offers protection from heat
- Easy to clean
- · Lightweight aluminium paddle



Specifications:

• Dimensions: 328 mm x 311 mm (13" x 12.3")

Recommended application:

To be used for taking all food items in and out of the high speed oven

Cleaning:

Wipe clean with a soft cloth or sponge in warm soapy water. To avoid damage always follow the recommended cleaning procedure. Do not use hard abrasives or wire wools on accessories.

